

Deterring Bears with Electrified Fencing: *A beginner's guide*



Russell L. Martin¹ and John M. Tomeček²

¹Wildlife Diversity Biologist, Texas Parks and Wildlife Department
²Assistant Professor and Extension Wildlife Specialist,
Texas A&M AgriLife Extension Service

Contents

| | |
|------------------------------------|---|
| Introduction | 1 |
| Getting Started | 1 |
| How Electrified Fencing Works..... | 2 |
| Components..... | 2 |
| Energizers..... | 2 |
| Grounding System | 4 |
| Wire..... | 5 |
| Posts..... | 7 |
| Insulators | 7 |
| Voltage meters..... | 7 |
| Electrified Net Fencing..... | 8 |
| Gates..... | 8 |
| Tips and Trouble Shooting | 9 |
| Additional Resources..... | 9 |

Introduction

The purpose of this guide is to provide basic information on properly designing an electrified fence for deterring bears. This guide is designed for people that have limited or no experience with electrified fencing but are interested in understanding the basics before designing a fence of their own. Proper design, construction, and maintenance will ultimately determine the effectiveness of your electrified fence.

A properly constructed electrified fence is safe for people, livestock, and pets and has proven effective at deterring bears from human-related resources such as beehives, garbage, or small livestock. However, safety is always a concern when using electrified equipment. Modern low impedance energizers have been designed to transfer energy fast enough that a spark generated along the electrical path should not produce enough heat to start a fire. Even though touching an electrified fence is unpleasant, modern energizers are safe and should not produce injury. However, it is always advisable to use common cautions around electrified fencing including:

- Do not touch an electrified wire or fence with your head, neck, or spine.
- Do not attempt to step over or climb through a fence that is electrified.
- Wear appropriate footwear when approaching an electrified fence.
- Never electrify barbed wire or use it as a ground-return wire.
- Hang warning signs in locations that will warn children, untrained adults, or visitors that your fence is electrified.
- Make your electrified fence as visible as possible.
- Never encourage anyone to touch an electrified fence.
- Never touch the positive and negative terminals of an energizer at the same time with

anything other than an appropriate electrified fencing voltage meter.

Getting Started

There are a few things to consider before designing your electrified fence:

- **Will your fence ever need to be moved or taken down?**

If so, consider a lightweight, temporary fencing design. There are many prefabricated electrified netting fences that are quick to install and easy to move. A fence constructed of polywire and plastic or fiberglass posts can be quickly set up for seasonal or short-term use. Alternatively, hog or cattle panels can be used to create small enclosures with several lines of electrified wires attached to the outside. While these fences are easier to construct than permanent fences, temporary fencing designs require more regular maintenance than permanent fencing to keep them running at optimal performance.

- **Will you use your electrified fence during months of snow and ice?**

Some electrified fencing materials handle snow and ice better than others. In winter, solar energizer units may not get enough sun to fully recharge batteries, or the batteries might freeze. Be prepared to do maintenance on fencing if you have a heavy snow or ice event. Fortunately, these events are rare in Texas, and bears should be less active when they occur.

- **Are dry weather periods common?**

Electrified fences rely upon moisture in the soil to conduct electricity that will deliver an effective electric shock. If the soil in your area becomes dry during certain months of the year, your fence will be on dry, rocky soil, or if your fence crosses pavement, wood, or concrete, you will need to design a ground-return fencing system. See the section on **Grounding Systems** for options.

- **Will your electrified fence need to secure hoofed livestock as well as exclude bears?**

Please check with your local agriculture Extension agent or other livestock experts for livestock appropriate fencing designs, and on how to train your livestock to respect an electrified fence.

- **How large of an area will your electrified fence enclose?**

For a large pasture, orchard, or property boundary fences, consider the size of the energizer needed to power your electric fence. Large acreage fences will need higher joule rated energizers to provide optimal power to the entire fence. See the section discussing **Energizers** for more information.

How Electrified Fencing Works

When an animal touches an electrified wire and the ground simultaneously, the electric current passes from the wire through the animal, into the ground, to the ground rod, and back to the energizer. The electrical current is then completed, and the animal receives a shock. However, if the soil is too dry or the ground rod is inadequate, the electric current will be unable to find a path back to the energizer, and the animal will receive little or no shock.

For an electrified fence to be effective against bears, the design should be constructed so that bears cannot climb through, over or under the fence without receiving a shock. This requires constructing a fence that:

- 1) Has multiple electrified wires (Fig. 1),
- 2) Is a combination of electrified and ground-return wires (Fig. 2),
- 3) Is a combination of electrified wires on the outside of an existing fence (Fig. 6), or
- 4) Is prefabricated electrified netting (Fig. 7).

Components

The six primary components of an electrified fence are:

- 1) Energizer,
 - a) All-hot fences
 - b) Ground-return fences
- 2) Grounding system,
- 3) Wires,
- 4) Posts,
- 5) Insulators, and
- 6) Voltage meter.

Additional materials may be necessary depending on the design of your particular fence. Other materials may simply add convenience—such as on/off throw switches—and can be added as desired.

1. Energizers

Energizers are the power source for your electrified fence. Energizers come in a wide variety of makes and models, but all of them are designed to store energy and deliver it in short pulses through the connected wires. To effectively deter bears, your energizer needs to pulse at a rate of 45 to 60 pulses per minute, which is approximately 1.0 to 1.5 pulses per second.

Energizer manufacturing companies rate their products with an energy measurement unit called a *joule*. A joule is a measure of stored or released energy. The joule rating of energizers typically has one of two classifications: stored or output. The stored classification is the maximum number of joules that the energizer can store when not delivering energy to a fence. The output classification is the maximum number of joules that the energizer can deliver to a fence. The number of joules stored will always be higher than the amount that can be delivered to the fence. For example, an energizer listed as having 1.0 stored joules will only be able to deliver approximately 0.7 joules to the fence.

The amount of stored or output joules does not translate to the amount of voltage an energizer can deliver nor to how powerful the electric shock will be. The higher the joule rating of an energizer means that it has a higher amperage. It is amperage, not voltage, that determines how powerful a shock will feel. For example, while both a 0.2 joule and 1.0 joule rated energizer can deliver a 7,000-volt shock, the 1.0 joule energizer has a higher amperage. Therefore, a 7,000-volt shock delivered by a 1.0 joule energizer will feel more powerful than a 7,000-volt shock from a 0.2 joule energizer. In plain terms, a 1.0 joule energizer has a more painful shock value than a 0.2 joule energizer.

Bears are more likely to pay attention to an electrified fence that delivers a painful shock. For deterring bears in developed areas, your energizer will require a minimum joule rating of:

0.7-1.0 stored joules or 0.5-0.7 output joules.

Note that energizers with 0.5 to 0.7 output joules will be advertised as energizing many more miles of fence than you may need; however, the higher output is required to be effective on bears. Low cost, slow pulse rate, low joule rated energizers are abundantly available and may be adequate for livestock or pet-yard applications. However, these energizers will not be effective at deterring bears.

High impedance energizers are also not recommended; these energizers may also be labeled as continuous current, weed burner, or weed chopper. High impedance energizers have a pulse that is long in duration, but low in energy. These long duration, continuous current pulses can create a spark that can produce enough heat to set fire to vegetation. Only low impedance energizers are recommended for deterring bears. Low impedance energizers have pulses that are short in duration, but higher in energy. Low impedance pulses are so short—less than 3/10,000 of a second—that a spark should not produce enough heat to start a fire. This short duration pulse also allows people and animals time to move away from a shock safely.

There are three basic models of energizers to choose from:

110-volt AC: These plug-in style energizers connect directly to a 110-volt outlet (standard household current). AC energizers are the least costly type of energizer to purchase and operate. Their standard pulse rate is 50 to 60 pulses per minute, receive consistent power and require less maintenance than DC-battery or solar units. Whenever possible, AC energizers are recommended for electrified fencing. Some styles of AC energizers have on/off switches while others have to be directly unplugged to be turned off.

DC-battery: These energizers receive their power from 6-volt or 12-volt DC (deep cycle) or marine batteries. These energizers are just as effective as their AC counterparts and are more versatile for location placement along your fence. However, because DC energizers do not come with batteries, the batteries that power the energizers are an added expense, making the overall cost of using DC energizers higher than AC energizers. To extend battery life, some DC energizers have a very slow per-minute pulse rate, so be certain to purchase one that pulses at the recommended 45 to 60 pulses per minute. The batteries that power DC energizers must be regularly recharged for your fence to remain at optimal performance; therefore, DC energizers will require more regular maintenance than AC energizers.

Solar: Solar energizers consist of a solar panel directly attached to both a rechargeable battery and a DC energizer, often sold as a single unit with battery and energizer enclosed in a case or housing. Solar panels can be purchased separately and added to a DC energizer, but the array must be powerful enough to keep a deep cycle battery charged. Your solar energizer must be placed in a location where it will receive enough sunlight to provide a sustainable charge for the battery. Because these units consist of three separate parts (solar panel, battery and energizer), solar energizers are the most expensive and highest maintenance option for powering an electrified fence.

2. Grounding System

Adequate grounding is an important component in the function of all electrified fencing. Without adequate grounding, an electrified fence will be unable to deliver an appropriate shock to an animal. Electricity must be able to easily flow from the soil to the grounding rod and back to the energizer for an animal to receive an adequate shock. For adequate grounding, all electrified fences will need a minimum of 3 to 6 feet of grounding rod per joule of stored energy from your energizer. **However, you cannot create too much grounding in your fencing design.** Inadequate grounding is the most common problem with electric fence performance and can be especially difficult to overcome in dry areas with rocky or sandy soils.

Grounding rods should be at least ½ inch in diameter and made of galvanized steel. Non-galvanized steel, rebar, steel posts or painted metals are not recommended as paint and rust are very poor conductors. Copper grounding rods may be used, but you should also use copper grounding wire and clamps to avoid electrolysis that can corrode connections. Be aware that the wire needs to be rated for 20,000 volts, and most household or industrial wire is rated for fewer than 1,000 volts. Never attach your electrified fence to a grounding rod used for a building's electrical system. Make sure that your ground rods are as far as possible from utility connections and water pipes. If electrical fencing grounding rods are too close to the utility grounding rods, they can cause interference in your utilities or electrical induction into your water pipes.

To form a proper connection, grounding rod clamps should be used to attach the energizer to the grounding rod. Grounding rods should be driven deeply into the ground near the energizer. The standard length of galvanized steel grounding rods are 6 to 8 feet and, if possible, a ground rod should be driven into the ground nearly its entire length. Dry or rocky soils do not conduct electricity well which reduces the

amount of energy that will reach back to a single grounding rod and the effectiveness of your electrified fence. In dry or rocky soils, several grounding rods should be used, driven as deep as possible, spaced 10 feet apart, and connected in a series. Another option is to bury a ground wire along the perimeter of the fence in addition to having ground rods. This will shorten the distance the current has to travel through the soil between the bear and the grounding system. If soils are very dry for several months each year, consider designing a ground-return electrified fence (as described on page 5) in addition to several deeply placed grounding rods.

a) All-hot fences

All-hot fencing designs are only appropriate for locations where the soil is moist year-round, either naturally or because of frequent watering. In an all-hot electrified fence design, all wires are electrified (hot or +). One wire is directly connected to the positive terminal on the energizer, and then all remaining wires are connected in a series to each other. The negative terminal on the energizer (ground or -) is directly connected to the grounding rod only. When an animal is standing directly on soil and touches just one of the electrified wires, it will receive a shock. The electrical current will travel from the energizer, through the wire, into the animal, into the soil, to the grounding rod, and back to the energizer. The electrical current is completed and results in the animal receiving a shock (Fig. 1).




Figure 1. An all-hot electrified fence design. All wires are connected to each other in series and to the positive terminal on the energizer. The negative terminal of the energizer is connected to the grounding rod.

For excluding bears, at least five electrified wires are recommended. Place the lowest wire approximately 8 to 12 inches above the ground and the top wire 36 to 42 inches high. Bears are not good jumpers, so electrified lines should be spaced to prevent a bear from going under, passing through, or climbing over the fence without fully touching at least one of the wires.

b) Ground-return fences

A ground-return design should be used in locations where soils are dry for much of the year, where soils are very rocky, or where conditions for deeply placing grounding rods is poor. This design consists of alternating hot (+) and ground (-) wires. One hot wire is directly connected to the energizer's positive terminal, and all remaining hot wires are connected to each other in a series. One ground wire is directly connected to the energizer's negative terminal, and all remaining ground wires are connected to each other in a series. The grounding rod is also directly connected to the energizer's negative terminal (Fig. 2). This design directly returns electrical current back to the energizer through all ground wires, instead of solely relying on conducting electricity back through the soil and grounding rod. The animal touches both a hot and a ground wire simultaneously to receive a full shock.

A minimum of five wires is recommended, with the top and bottom lines hot. Place the lowest wire approximately 8 to 12 inches above the ground and the top wire 36 to 42 inches high. Bears are not good jumpers, so lines should be spaced to prevent a bear from going under, passing through, or climbing over the fence without fully touching two of the wires.

Based on the principals of these two different wiring systems, there are many fence designs that can be created. For example, if you already have a fence constructed of net-wire and t-posts, you can add several electrical lines on the outside of the net-wire fence to prevent a bear from climbing over, under, or pushing




Figure 2. A ground-return electrified fence design. All hot wires are connected to each other in a series and to the positive terminal on the energizer. All ground wires are connected to each other and to the negative terminal on the energizer. The negative terminal of the energizer is also connected to a grounding rod.

through the fence. The net-wire fence would be connected directly to the energizer's negative terminal and act as the fences ground (-) lines. This creates another type of *ground-return fence*. When a bear touches one of the hotlines and the grounded net-wire together, they will receive a full electric shock that does not require the energy to travel through the soil to complete the circuit (Fig. 6 on page 7).

3. Wire

Galvanized smooth steel or aluminum wire should always be used in the construction of a permanent electrified fence. Galvanized smooth steel wire is strong and durable but rigid, and larger gauges can be difficult to tighten in small fence designs. Aluminum wire is lightweight and easy to use but will break with repeated bending. No matter which style you choose, a permanent electrified fence is most effective when designed with 12- or 14-gauge wire. For some, very small, fence designs that cover short distances, 16-gauge wire could be considered. Alternatively, very large fences covering long distances should be created with 10- or 12-gauge wire.

For temporary, seasonal, or portable electrified fencing, consider the use of polyethylene wire, also called polywire (Fig. 3). Polywire consists of many strands of wire braided within a polyethylene rope. Polywire is flexible, strong and can




Figure 3. Two different styles of 9-stranded Polywire

be unrolled and re-rolled multiple times without breaking. It is recommended that your polywire have at least nine strands of wire imbedded within the polyethylene. Polywire will degrade and break after long exposures to sunlight. Polytape, which is flat instead of rope-like, is less effective for deterring bears and is not recommended.

To connect energizers to fences, multiple strands of fencing wire in a series, or to connect multiple sections of fencing together, use insulated wire of 10- to 14-gauge specifically designed for electrified fences (Fig. 4). This type of wire may also be called *insulated underground wire* and is rated for 20,000 volts. Do not use household or industrial wire as they are rated for fewer than 1,000 volts and are not appropriate for an electrified fencing system.



Figure 4. Black-colored insulated electric fence wire, 12-gauge. Used here to connect the electrified lines of a gate to the main electrified lines on the fence.

Design ideas

Depending on the size of your fence and the application, net-wire fencing, or wire panels can be used with or in place of single-stranded electrified wire fences. For example, wire panels or net-wire fencing can be raised completely off the ground by attaching them to fiberglass posts, and then fully electrified. The wire panel or net-wire fence would be directly attached to the positive terminal of the energizer (Fig. 5). Because they are raised above the soil and attached to fiberglass posts, the panels would be insulated and remain fully electrified, similar to an all-hot wire fence design.




Figure 5. Electrified rigid wire panel. The panel is raised off the ground and insulated by hanging it from fiberglass posts. The wire panel is electrified by connecting it directly to the positive terminal on the energizer. The ground rod is connected to the negative terminal of the energizer.

Alternatively, wire panels or existing net-wire fence could be used as grounded wires in a ground-return wire fence design. A minimum of three electrified wires would be added to the outside of the panels or net-wire fence to prevent a bear from climbing over, under, or pushing through the existing fence. The wire panel or net-wire fence is connected directly to the energizer's negative terminal. When an animal touches one of the hotlines and the grounded net-wire together, it will receive a full electric shock that does not require the energy to travel through the soil to complete the circuit (Fig. 6).




Figure 6. Rigid wire panel or net-wire fencing with three electrified wires attached to the outside of the fence. The electrified wires are connected in a series and attached to the positive terminal of the energizer. Then, panel or net-wire fence is connected to the negative terminal of the energizer. The ground rod is also connected to the negative terminal of the energizer.

4. Posts

The primary difference between a permanent and temporary electrified fence is your choice of fencing posts and the extent to which they are installed. For low maintenance, permanent fences, treated wooden posts are the best choice—particularly for the corner posts. Less permanent fences can be constructed using metal t-posts or fiberglass posts. Seasonal use or portable fences are typically constructed using “step-in-the-ground” plastic posts or fiberglass posts. Wooden posts and metal t-posts should be braced at corners and gates. Flexible plastic and fiberglass posts will need support lines placed on the outside of corners and wherever the fence has an abrupt ending.

5. Insulators

To prevent electrified wires from leaking energy into the soil through conductive materials, wooden posts and metal t-posts will need the additional expense of insulators to hold electrified wires away from the posts. Insulators are commonly made of plastic or ceramic and are clipped on to t-posts or screwed into wooden posts. There are hundreds of types of insulators available, all designed for different uses and fencing system designs. Look for insulators that are the most suitable for the posts and design of your particular fence.

For electrified wires added to the outside of net-wire fences or wire panels, look for insulators that will hold electrified wires 4 to 6 inches away from posts and metal fencing. For wooden corner posts and end posts, heavy-duty lag-corner bolts are recommended and should be placed so that the wire can complete a 90-degree turn without any part of it touching the post.

Plastic and fiberglass are non-conductive materials and do not usually need insulators added to them. These posts typically come with built-in clips or notches to hold up each line of electrified wire. Holes can be even drilled through the posts to feed the electrified wire directly through them.

6. Voltage meters

Regular and proper maintenance will ultimately determine the effectiveness of your electrified fence. Your most important maintenance tool is an electric fence voltage meter, sometimes called a fence tester. This small device tells you not only if your energizer and grounding system are functioning properly, but also the amount of voltage passing through your electrified wires. This is not the same as a voltage reader. Voltage readers only tell you if electrical current is passing through a wire. A voltage meter tells you how much voltage is passing through a wire, which is what matters in this case. Bears require a minimum of 5,000 to 7,000 volts of electricity to be deterred—depending on the species and the bear’s level of experience.

Voltage meters come in everything from inexpensive models, with multiple LED lights that light up when a certain amount of voltage passes through it, to more expensive models, with an exact digital readout of the amount of voltage passing through it. Voltage meters designed for use on a vehicle or household current are inadequate to use on an electrified fence. Electric fence voltage meters should be used to test the functionality of a fence immediately after setup and then periodically thereafter as a part of regular fence maintenance.

Electrified Net Fencing

Prefabricated electrified netting creates quick and easy temporary fences that can be used to keep out wildlife. These fences were designed to create small, moveable grazing pastures for small livestock, such as chickens, sheep, and goats while keeping them safe from predators. They can be used to prevent bears from accessing fruit trees, deer feeders, chicken coops, garbage, or anywhere else bears need to be excluded from. Electrified netting is a combination of horizontal and vertical polywires permanently attached to step-in-the-ground posts (Fig. 7). They are commonly premanufactured in 25- to 164-foot lengths and can be connected in series to create longer or shorter fences.

These fences are fully portable and require no special tools to install. The only additional materials needed is an energizer and grounding rod. Electrified netting does not need to connect back onto itself (i.e., create a circle) in order to function. Some drawbacks of these fences are that they are meant for temporary use and will need regular adjusting to prevent sagging over time. The fence line will need to be moved



Figure 7. A premanufactured ground-return (pos/neg) electric net fence. The orange horizontal wires are electrified, and the green horizontal wires are grounded. The vertical black lines are non-conductive and secure the horizontal wires in place.

for regular weed cutting or mowing, they are difficult to place in hard ground, and the fences do not handle snow or ice loads well. This type of fence does not deter deer, but they can pull up and possibly damage the fence when attempting to jump over. Electrified netting comes in all-hot or ground-return (commonly called pos/neg) designs. For excluding bears, the ground-return (pos/neg) design is recommended.

Gates

A common question people have is how to deal with gates in the design of an electrified fence. If a gate is the only non-electrified portion of a fence, a bear is likely to discover it and use that spot to gain access to whatever is behind the fence. Therefore, whenever possible, electrify gates as well. Think of gates as miniature sections of fencing. Place electrified wires on the outside of the gate the same way they would be placed on a main section of fencing but take care not to have electrified wires too close to gate handles. The wires on a gate are electrified by attaching one of the wires to the main fence with insulated electric fencing wire, as previ-




Figure 8. An example of how a gate can be electrified by attaching it to the electrified lines on the main fence, and how two sections of fence can be electrified with an underground wire connection.

ously seen in Figure 4. Additional wires on the gate are electrified by attaching them in a series to the wire connected to the main fence. To connect two sections of fencing together with a gate in between, insulated electric fencing wire can be run in the ground under the gate or over the gate if an archway exists (Fig. 8).

Tips and Trouble Shooting

- Grounding is the most important component in the design of your electrified fence. Inadequately grounded fences will deliver weak shocks and be ineffective for deterring bears.
- If using a solar or DC operated energizer, check the charge on your battery often. Check battery terminals for corrosion and adequate connection.
- Check that electrified wires are not touching heavy vegetation, fallen branches, posts, or other wires.
- Check for poor connections in spots where electrified wires have been spliced together. When possible, use crimp sleeves, brass ferules, or other splicers to make connections.
- Check the voltage on electrified wires weekly and as part of routine fence maintenance.
- Place electric fencing signs along the perimeter of your fence and at gates to improve visibility and warn people the fence is electrified.
- Whenever possible, place fencing 3 to 5 feet away from the structures they are protecting, such as chicken coops or rabbit hutches. You

want the bear to encounter the electrified fence before reaching the structure itself.

- When protecting fruiting trees, place your electrified fence so that all fruit falls inside the fence boundary instead of outside it.
- Place the fence energizer inside the area protected by the fence to prevent bears from damaging it.

Additional Resources

Once you have a basic understanding of how an electrified fence functions, you can create many designs with these basic concepts in mind. You can create an electrified mat that lies flat on the ground to prevent bears from accessing a doorway, gateway, or driveway. You could electrify a metal bird feeder, a door, or even harvested game using these basic electrified fencing concepts. For more information on how to create these and other unique fences, please visit:

Montana Department of Fish, Wildlife & Parks at www.fwp.mt.gov

- Search for “Bear Aware” from the homepage

Defenders of Wildlife at www.defenders.org/got-grizzlies

- *How to Install an Electric Fence* video, information on their electric fencing incentive program

Gillian Sanders from BC, Canada <https://www.youtube.com/watch?v=lqIRMavnahE>

- *How to Electric Fence Against Bears* video

This guide was adapted by the TPWD and Texas AgriLife Extension authors and originally prepared by Kim Annis Grizzly and Black Bear Conflict Specialist; Montana Fish, Wildlife & Parks

March 2017 – version 3.0

Texas A&M AgriLife Extension Service

AgriLifeExtension.tamu.edu

Texas A&M AgriLife Extension provides equal opportunities in its programs and employment to all persons, regardless of race, color, sex, religion, national origin, disability, age, genetic information, veteran status, sexual orientation, or gender identity.